

## Application Note – Visilogics dual instance

### Dual instances of Visilogics software

It is possible to run more than one instance of Visilogics software on a PC using the following instructions. This has only been tested on W7 & W8 (64 bit) and an important point to note is that any updates (OS, Help, Language etc) must be made to BOTH instances.

1. Duplicate (copy and paste in the same place) the folder C:\Program Files\Unitronics\Unitronics Visilogic\_C in C:\Program Files\Unitronics.
2. Rename the new folder for example to Unitronics Visilogic\_C2.
3. Open the folder C:\Program Files\Unitronics\Unitronics VisiLogic\_C2\VisiLogic Self Reg DLLs and delete all its content.
4. Open the folder C:\Program Files\Unitronics\Unitronics VisiLogic\_C2\Data\FB\_Lib\DII and delete all its content.
5. Now go to the folder C:\Program Files\Unitronics\Unitronics VisiLogic\_C2\Main and create a shortcut for the file VisiLogic.exe (you can rename the shortcut as VisiLogic 2) or create a shortcut on your desktop to "C:\Program Files\Unitronics\Unitronics VisiLogic\_C2\Main\VisiLogic.exe"

Please note that you will not be able to copy elements between the 2 instances of VisiLogic.

#### Upgrading of software

Delete the folder C:\Program Files\Unitronics\Unitronics VisiLogic\_C2

If you want to keep the old version of Visilogics on your PC then rename the directory  
C:\Program Files\Unitronics\Unitronics VisiLogic\_C to  
C:\Program Files\Unitronics\Unitronics VisiLogic\_xx  
where xx is the version number, or a name of your choice.

Delete the shortcut to the second instance of the software. Run the software update selecting the 'repair' option when requested to do so.

Follow steps 1-5 above for the second instance.